

CLI Commands

The CLI is designed around a tree structure of the configuration settings. This configuration tree best represents the configuration data the operator needs to modify. This data tree is manipulated directly, and no “set” keyword is necessary. However, the following commands are implemented to allow the operator to work with the other aspects of the modem. All index numbers used are 1’s based unless otherwise specified.

Global Commands

The following CLI commands are available from **all contexts**.

apply

command

Description:

When a configuration setting is changed, the new configuration is not activated immediately. New Configuration will be activated in the system only when the “apply” command is executed,

Warning:

- The apply command does not save the configuration in flash memory. Apply only modifies the running configuration in RAM
 - The apply command must be issued prior to leaving the WAN connection context.
 - The apply command when issued in conjunction with changes in the AP will cause the AP to restart.
-

configure

command

configure [terminal]

Description:

This command sets the CLI to configuration mode. If the optional command terminal is used this allows configuration commands to read from the terminal.

disable

command

disable

Description:

This command sets the CLI privilege mode to 0.

discard

command

Description:

This command discards any pending changes to the system.

enable

command

enable [<level>]

Description:

This command allows the user to enter a CLI privilege mode. The user can enter a privilege level from 0 to 5. The system will prompt for the specific level password. The levels are:

0. nobody: Default user when first logging in. This level allows the user to view statistics and system information. System changes and the display of settings are not allowed. (No password needed)
 1. view: This level allows the user to view statistics, system information, and settings. System changes are not allowed. (Default password: “view”)
 2. logger: This level allows the user to view statistics, system information, and settings. Changes to log settings are allowed. (Default password: “logger”)
 5. admin: This level allows the user to view statistics, system information, and settings. Changes to all settings are allowed. (Default password: “Admin”)
-

end

command

Description:

Leave the current context and move the operator to the root context.

exit

command

Description:

Leave the current context and move the operator “up” one level. There is no way to “exit” the root context.

generate

command

Description:

Generate a list of CLI commands that contains all the CLI commands that would be needed to recreate the current configuration. This command list can be captured, and replayed to another modem to provide duplicate settings.

help

command

Description:

This command displays a brief listing of user-level commands.

logoff

command

Description:

This command allows the operator to exit the CLI interface. The logoff command can be executed from any context. Any current commands not saved or applied prior to the logoff command will be lost.

quit

command

Description:

This command will terminate the CLI from any nested level.

reboot

command

reboot [yes]

Description:

Perform a reboot of the modem. The yes option will just reboot without a yes/no prompt.

save

command

Description:

This command records the current configuration into flash. This command must be used to have the current settings preserved upon system reboot.

Warning:

- Configuration changes must be applied before saving them. The user will be prompted to apply the changes before the save command is issued.
-

show

command

Description:

This command shows the current configuration tree settings. If “show” is entered without any parameters, all the settings from the current context will be displayed, additionally, all the sub-contexts will be recursively traversed, and the settings within those sub-contexts will also be shown. If the show command is entered with a parameter, the show command will only show that parameter’s settings

show log

command

Configures:

Default:

Description:

Show the log records

show enet-stats

command

Configures:

Default:

Description:

Show the statistics information of Ethernet interface

show usb-stats

command

Configures:

Default:

Description:

Show the statistics information of USB interface

show dsl-stats

command

Configures:

Default:

Description:

Show the statistics information of DSL interface

show wireless-stats

command

Configures:

Default:

Description:

Show the statistics information of wireless interface

show modem-stats

command

Configures:

Default:

Description:

Show the statistics information of modem

show product-info

command

Configures:

Default:

Description:

Show the product information

Root - Context

The following CLI commands are available from the ROOT context.

ap

root

ap

Default: None

Description:

Sets the context to ap context

lan

root

lan

Default: None

Description:

Sets the context to lan context

product-info

root

product-info

Default: None

Description:

Provides a product information list.

shell

root

Description:

Provides a way for the operator to get access to the system's shell.

show [all]

root

Configures:

Default:

Description:

Show all configuration information of all subcontext

show log-config

root

Configures:

Default:

Description:

Display the configuration of remote logging

show status

root

Configures:

Default: 100-full

Description:

Show the information of the system

stats

root

stats [network {Ethernet | usb | dsl | wireless}] [modem] [connection]

Default: None

Description:

Provides a list of all the current interface and connection stats on the modem.

system

root

system

Default: None

Description:

Sets the context to system context

wan

root

wan

Default: None

Description:

Sets the context to wan context

Root: SYSTEM - context

The following CLI commands are available from a SYSTEM context.

log level

system

log level {panic | alert | critical | error | warning | notice | notice | info | debug }

Configures: The current log level of the system

Default: notice

Description:

This command sets the log level for debug information.

log remote

system

log remote add

log remote add <ip_addr>

Configures: Remote Logging IP addresses

Default: 0.0.0.0 for all parameters

Description:

This command set the IP address of a remote logging machine.

log remote del

system

log remote del <ip-address>

Configures: Delete remote logging IP addresses

Default: None

Description:

This command deletes a remote logging machine by specifying its IP address.

log remote flush

system

log remote flush

Configures: Delete all remote logging IP addresses

Default: None

Description:

This command deletes all remote logging machines.

password

system

password {admin | user } <password-string>

Configures: Password associated with the particular CLI privilege mode

Default: None

Description:

This command sets the password associated with a particular CLI privilege mode.

reset factory-defaults

system

reset factory-defaults [yes]

Configures: Restores the system to factory default settings.

Default: Pre-stored system default parameters

Description:

This command restores the system defaults. The user must execute the **reboot** command to make the factory-default settings active. If the yes option is given the user will not be prompted with a yes/no prompt.

ROOT: LAN - Context

The following CLI commands are available from the LAN context.

host-name

lan

host-name <name-string>

Configures: Host name of the modem

Default: None

Description:

This command sets the host name that the modem will use.

domain-name

lan

domain-name <name-string>

Configures: Domain name of the modem

Default: None

Description:

This command set the domain name that the modem will use to complete any unqualified domain names.

port configure

lan

port <port-number> { auto | 10-half | 10-full | 100-half | 100-full }

Configures: The Ethernet physical interface specified by port-number. \

Default: 100-full

Description:

Configure Ethernet physical interfaces with the desired parameters. Range for port-number is <1..4>

port assign

lan

port assign { usb | wlan | eth0 | none } { lan1 | lan2 | lan3 }

Configures: LAN Groups

Default: None

Description: This command assigns interface ports, i.e. usb etc. to a particular LAN GROUP. There are 3 possible LAN Groups.

lan-group

lan

lan-group <num>

Configures: LAN Groups

Default: None

Description: This command sets the context to a particular LAN group.

management type

lan

management type {static | dynamic | unmanaged}

Configures: LAN Groups

Default: None

Description: This command sets the management type of a particular LAN group.

port assign

lan

port assign {usb | ap | eth0} {lan1 | lan2 | lan3 | unassigned}

Configures: LAN Groups

Default: None

Description: This command assigns a port to a particular LAN group.

show [all]

lan

Configures:

Default:

Description:

Show all LAN configuration information

show lan-group

lan

Configures:

Default:

Description:

Show the list of lan-groups

ROOT: LAN: GROUP <#> - Context

The following CLI commands are available from the LAN GROUP <#> context. Enter LAN context then GROUP context with a LAN GROUP number to configure a particular managed or unmanaged LAN GROUP. The “lan connection <#>” context is entered in the CLI by entering “lan group” followed by the group number from 1 to 3, e.g. “lan group 1” and then carriage return. All commands entered within the lan group <#> context have local significance only to that context.

management type

lan group <#>

management type {unmanaged | static | dynamic}

Configures: Management type for LAN Groups

Default: None.

Description:

This command sets the management type for a particular LAN group.

static

lan group <#>

static <ip-address> [netmask <mask>] [gateway <ip-address>]

Configures: A LAN group with a static IP.

Default: The netmask defaults to a class C network, but can be configured.

Description:

This command configures a static IP for a LAN Group.

dhcp off

lan group <#>

dhcp off

Configures: Disables the DHCP Server/Relay

Default: DHCP server on.

Description:

Disables the DHCP Server/Relay. To turn the DHCP server on execute the command **dhcp server**. To turn the DHCP relay on execute the command **dhcp relay**.

dhcp server

lan group <#>

dhcp server start <ip-address> end <ip-address> [lease <lease-time>]

Configures: DHCP Server

Default: The starting and ending IP addresses are calculated from the settings given to the LAN interface. Lease time = 3600 seconds.

Description:

This command without parameters will turn the DHCP server on. The command is also used to configure the optional parameters for the server.

Parameters:

start: Starting IP address to be served

end: Ending IP address to be served

lease: Lease time in seconds.

Warning: This command only works when the LAN management group type is static.

dhcp relay

lan group <#>

dhcp relay [<ip-address>]

Configures: DHCP Relay

Default: None

Description:

This command is used to enable and configure the DHCP relay.

Warning: This command only works when the LAN management group type is static.

dhcp client-static add

lan group <#>

dhcp client-static add <ip-address> <mac-address> [hostname <name-string>]

Configures: Static LAN clients.

Default: None

Description:

This command adds static LAN clients. This command differs from the dhcp client-reserve because it is used for static allocation of client IP addresses, while dhcp-reserve is used for reserving IP addresses which have been dynamically allocated.

dhcp client-static del

lan group <#>

dhcp client-static del <index-number>

Configures: Static LAN clients.

Default: None

Description:

This command is used to delete a specific static or dynamic LAN client by specifying an IP address from a list of LAN clients. Use **show dhcp-static** to get a listing of valid client IP's and their associated index numbers.

dhcp client-static clear lan group <#>

dhcp client-clear

Configures: Static LAN clients.

Default: None

Description:

This command deletes all static LAN clients.

dhcp client-dynamic reserve lan group <#>

dhcp client-reserve <index-number >

Configures: Reserves IP Addresses for LAN clients from dynamically allocated IP's

Default: None

Description:

This command is used to reserve a dynamic DHCP address for a LAN client by specifying an index number. Use **show dhcp-dynamic** to get a listing of valid dynamic client IP's and their associated index numbers.

dhcp client-dynamic del lan group <#>

dhcp client-del <index number>

Configures: Deletes IP Addresses for LAN clients from dynamically allocated IP's

Default: None

Description:

This command is used to delete a dynamic DHCP address for a LAN client by specifying an index number. Use **show dhcp-dynamic** to get a listing of valid dynamic client IP's and their associated index numbers.

dhcp client-dynamic clear lan group <#>

dhcp client-dynamic clear

Configures: Deletes all IP Addresses for LAN clients from dynamically allocated IP's

Default: None

Description:

This command deletes all IP entries that have been reserved from dynamically allocated IP's.

nat lan group <#>
nat {enable | disable}

Configures: Enables NAT functionality for a LAN group.

Default: enabled

Description:

Enable/Disable NAT.

firewall lan group <#>
firewall {enable | disable}

Configures: Enables the firewall functionality for a LAN group.

Default: enabled

Description:

Enable/Disable the firewall.

upnp lan group <#>
upnp {enable | disable}

Configures: Enables the UPnP functionality for a particular connection.

Default: disabled

Description:

Enable/Disable UPnP. UPnP can only be active on a single connection at a time.

port forward lan group <#>
port forward {enable | disable}

Configures: Port Forwarding.

Default: None

Description:

This command enables Port Forwarding.

port forward rule-add lan group <#>

port forward rule-add [parameters]

Configures: Port Forwarding Rules for a particular connection.

Default: None

Description:

This command allows the user to add rules for the port forwarding function. A connection must be specified for which the rule applies.

Parameters:

name <rule-name>

protocol <tcp | udp | tcp-udp | any>

src-ip <ip-address>

src-netmask <mask>

dst-ip <ip-address>

dst-netmask <mask>

port-start <port-number>

Starting value of port numbers to be used. Range <0..65535>

port-end <port-number>

Ending value of port numbers to be used. Range <0..65535> and greater than the Start Value.

port-map <port-number>

Port map specifies the starting port number from which to re-map the range of port numbers given by port-start, and port-end.

port forward rule-del

lan group <#>

port forward rule-del <index-number>

Configures: Port Forwarding Rules.

Default: None

Description:

This command allows the user to delete a specific rule for the port forwarding function. Use **show port forward rule** to get a listing of valid port forward rules and their associated index numbers.

port forward rule-clear

lan group <#>

port forward rule-clear

Configures: Port Forwarding Rules.

Default: None

Description:

This command clears all rules for the port forwarding function.

dmz lan group <#>

dmz {enable | disable}

Configures: DMZ

Default: None

Description:

This command enables DMZ functionality.

dmz client-add lan group <#>

dmz client-add <ip-address>

Configures: DMZ

Default: None

Description:

This command allows the user to set the LAN client IP used for the DMZ. Only one LAN client IP can be specified at a time. The client IP must be chosen from those added through **dhcp client-static add**. A command does not exist to explicitly clear a client IP address because these are added and deleted via the **dhcp client-static add** and **delete** commands. The **dmz {disable}** command must be used to disable the dmz while a dhcp client-static IP address exists on the system.

ipqos lan group <#>

ipqos {enable | disable}

Configures: Enables IP QoS services on the egress side of a connection interface.

Default: Disabled

Description:

IP QoS services in the NSP is applicable to the output device (Egress side). IP QoS traffic shaping is associated with any transmitted traffic from the perspective of the NSP. Each output device has 3 priority queues associated with any transmit traffic. The High priority queue has strict priority over the medium and low priority queues. The Medium and Low priority queues are serviced on a Round Robin priority basis according to the configured weights (WRR) set with the ipqos queue command, after the High priority queue has been completely serviced.

ipqos trusted-mode lan group <#>

ipqos trusted-mode {enable | disable}

Configures: The trusted mode for IP QoS services.

Default: Disabled

Description:

The NSP can operate in either “Trusted” (enabled) or “Untrusted” (disabled) mode of operation with regard to queue traffic prioritization. In “Trusted” mode all the rules will be applied first, regardless of the setting of the TOS bits. After the rules have been exhausted the existing TOS bit settings will be honored. The “Un-trusted” mode will match first against all rules as in “Trusted” mode. The difference is that if there is no match then a default rule will be used. The default rule will have an associated queuing priority – Low.

ipqos queue

lan group <#>

ipqos queue [low <percentage>] [med <percentage>]

Configures: The low and medium priority queues used on transmit traffic from the modem.

Default: low = 40, med = 60

Description:

This command allows the setting of the Low and Medium priority queues in increments of 10 percent, so that the sum of the weights of these two queues equals 100 percent.

ipqos rule-add

lan group <#>

ipqos rule-add <name-string> [parameters]

Configures: Add rules to be used by IP QoS priority queues.

Default: None

Description:

This command allows a user to specify new rules for Add new rules for queuing transmit traffic. One or more of the following parameters can be specified. Wildcard (*) entries are allowed for IP Address/Netmask and Port range fields.

Parameters:

```
src-ip: <ip-address>
src-netmask: <mask>
src-start-port: <ip-address>
src-end-port: <ip-address>
dst-ip: <ip-address>
dst-netmask: <mask>
dst-start-port: <ip-address>
dst-end-port: <ip-address>
protocol: {any | icmp | tcp | udp}
physical-port <port-number>
```

priority {low | medium | high}: Select the queue priority for this rule.
tos { no-change | normal | min-cost | max-reliability | max-throughput | min-delay
}

ipqos rule-del

lan group <#>

ipqos rule-del <index-number>

Configures: Delete rules to be used by IP QoS priority queues.

Default: None

Description:

This command deletes a rule specified by index-number from the list of rules used for IP QoS on a particular connection. Use **show ipqos rule** to get a listing of valid ipqos rules and their associated index numbers.

ipqos rule-clear

lan group <#>

ipqos rule-clear

Configures: Delete all rules to be used by IP QoS priority queues.

Default: None

Description:

This command deletes all rules used for IP QoS on a particular connection.

route static-add

lan group <#>

route static add <destination-ip> <netmask> <gateway-ip> [metric {0 | 1}]

Configures: Static routes

Default: metric = 0

Description:

This command is used to add and configure static routes.

route static-del

lan group <#>

route static-del <index-number>

Configures: Static routes

Default: metric = 0

Description:

This command is used to delete a static route by specifying its index number. Use **show route static** to get a listing of valid static routes and their associated index numbers.

route static-clear lan group <#>
route static-clear

Configures: Static routes

Default: metric = 0

Description:

This command is used to delete all static routes.

bridge filter lan group <#>
bridge filter {enable | disable}

Configures: The bridge filter

Default: disabled

Description:

This command enables the bridge filter. The bridge filtering mechanism provides a way for users to define rules to allow/deny frames through the bridge based on source MAC address, destination MAC address and/or frame type and port number. When bridge filtering is enabled, each frame is examined against each defined filter rule in a sequential order. When a match is determined, the appropriate filtering action (determined by the access type selected, i.e. allow or deny) is performed.

bridge filter rule add mode lan group <#>
bridge filter rule add mode {deny | allow} [parameters]

Configures: Add bridge filter rules.

Default: None

Description:

This command allows the addition of new bridge filter rules. A maximum of 20 rules can be added. The following parameters can be specified:

Parameters:

- src-mac <mac-address>
- src-port {s-any | s-usb | s-ethernet | s-wlan}
- dst-mac <mac-address>
- dst-port {d-any | d-usb | d-ethernet | d-wlan}
- protocol {any | ipv4 | ipv6 | arp | rarp | ipx | pppoe-discovery | pppoe-session}
- mode {deny | allow}
- port <port-number>

bridge filter rule del lan group <#>

bridge filter rule del <index-number>

Configures: Deletes user defined rules for the bridge filter

Default: None

Description:

This command deletes a particular bridge filter rule given by filter-number. Use **show bridge filter rule** to get a listing of valid bridge filter rules and their associated index numbers

bridge filter clear

lan group <#>

bridge filter clear

Configures: Bridge Filter

Default: None

Description:

This command flushes the bridge filter table entries.

bridge filter management-port

lan group <#>

bridge filter management-port {enable | disable} [port <port-name>]

Configures: Bridge Filter

Default: Disabled

Description:

This command enables the bridge filter management port and specifies the port name.

ip filter add rule

lan group <#>

ip filter add rule <name-string> [parameters]

Configures: IP Filter rules

Default: None

Description:

This command allows the user to add rules to the Firewall to block IP traffic between the WAN and the LAN interface on the modem.

Parameters:

src-ip <ip-address>: interfaces on the LAN side.

src-netmask <mask>

dst-ip <ip-address>: interfaces on the WAN side.

```
dst-netmask <mask>
protocol <any | tcp | udp | tcp-udp | icmp>]
portStart <port-start>
portEnd <port-end>
```

ip filter del rule

lan group <#>

```
ip filter del rule <index-number>
```

Configures: IP Filter rules

Default: None

Description:

This command allows the user to delete Firewall rules. Use **show ip filter rule** to get a listing of valid ip filter rules and their associated index numbers.

ip filter del clear

lan group <#>

```
ip filter del clear
```

Configures: IP Filter rules

Default: None

Description:

This command allows the user to clear all Firewall rules.

access-list

lan group <#>

```
access-list {enable | disable}
```

Configures: Access control

Default: None

Description:

This command enables the access control list for the modem.

access-list service

lan group <#>

```
access-list service [parameters]
```

Configures: Access control list

Default: None

Description:

This command enables services for the access control list.

Parameters:

telnet <enable | disable>

web <enable | disable>

ftp <enable | disable>

tftp <enable | disable>

ssh <enable | disable>

snmp <enable | disable>

access-list ip add

lan group <#>

access-list ip add <ip-address>

Configures: Access control list

Default: None

Description:

This command adds IP addresses on the access control list.

Warning: The IP addresses assigned through this command have a global scope.

access-list ip del

lan group <#>

access-list ip del <index-number>

Configures: Access control list

Default: None

Description:

This command deletes IP addresses on the access control list. Use **show access-list** to get a listing of valid access-list ip numbers and their associated index numbers.

access-list ip clear

lan group <#>

access-list ip clear

Configures: Access control list

Default: None

Description:

This command deletes all IP addresses on the access control list.

show [all] lan group <#>

Configures:

Default:

Description:

Show all configuration of the LAN group

show management lan group <#>

Configures:

Default:

Description:

Show the management setting of the LAN group

show static lan group <#>

Configures:

Default:

Description:

Show the static setting of the LAN group

show dynamic lan group <#>

Configures:

Default:

Description:

Show the dynamic (DHCP) setting of the LAN group

show lan-config lan group <#>

Configures:

Default:

Description:

Show the configuration setting of the LAN group

show bridge-filter

lan group <#>

Configures:

Default:

Description:

Show the bridge filter information

show ip-filter

lan group <#>

Configures:

Default:

Description:

Show the IP filter information

show lan-client

lan group <#>

Configures:

Default:

Description:

Show LAN client information

show dhcp-client

lan group <#>

Configures:

Default:

Description:

Show DHCP client information

show access-list

lan group <#>

Configures:

Default:

Description:

Show access control list information of the LAN group

ROOT: WAN - CONTEXT

The following CLI commands are available from the WAN context.

connection

wan

connection <num>

Configures: Sets WAN connection context

Default: None

Description:

This command is used to set the WAN context to a particular connection number. Range <1..8>

modulation

wan

modulation {t1413 | gdmr | glite | mmode}

Configures: Sets the modulation type of the DSL modem

Default: mmode

Description:

This command is used to set the DSL modulation type.

modem test

wan

modem test <vpi> <vci> {f5end | f5seg | f4end | f4seg}

Configures: Sends a test F4 or F5 OAM ping on a specific PVC.

Default: None

Description:

This command sends a test F4 or F5 OAM ping on a specific PVC given by the pvc vci/vpi pair. A valid vpi/vci pair must be entered for the command to succeed. This command is used to check the connectivity of the modem to the network.

access-list

wan

access-list {enable | disable}

Configures: Access control

Default: None

Description:

This command enables the access control list for the modem.

access-list service

wan

access-list service [parameters]

Configures: Access control list

Default: None

Description:

This command enables services for the access control list.

Parameters:

telnet <enable | disable>

web <enable | disable>

ftp <enable | disable>

tftp <enable | disable>

ssh <enable | disable>

snmp <enable | disable>

access-list ip add

wan

access-list ip add <ip-address>

Configures: Access control list

Default: None

Description:

This command adds IP addresses on the access control list.

Warning: The IP addresses assigned through this command have a global scope.

access-list ip del

wan

access-list ip del <index-number>

Configures: Access control list

Default: None

Description:

This command deletes IP addresses on the access control list. Use **show access-list** to get a listing of valid access-list ip numbers and their associated index numbers.

access-list ip clear

wan

access-list ip clear

Configures: Access control list

Default: None

Description:

This command deletes all IP addresses on the access control list.

show [all]

wan

Configures:

Default:

Description:

Show all WAN configuration information

show modulation

wan

Configures:

Default:

Description:

Show ATM modulation type

show connections

wan

Configures:

Default:

Description:

Show the list of all connections

show access-list

wan

Configures:

Default:

Description:

Show access control list information of WAN

ROOT: WAN: CONNECTION <#> - Context

The following CLI commands are available from the WAN context. Enter WAN context with a connection number to configure a particular WAN connection. The “wan connection <#>” context is entered in the CLI by entering “wan connection” followed by the connection number from 1 to 8, e.g. “wan connection 1” and then carriage return. All commands entered within the wan connection <#> context have local significance only to that context.

connection type

wan connection <#>

connection type {off | pppoe | pppoa | static | dhcp | bridge | clip}

Configures: The type of interface for this particular connection

Default: None.

Description:

Select the connection type. Additional settings for individual types are given below under their respective names.

Parameters:

off: Disables the connection.

pppoe: Configure this connection to be a PPPoE connection.

pppoa: Configure this connection to be a PPPoA connection.

static: Configure this connection to be a static connection.

bridge: Configure this connection to be a bridged connection.

clip: Configure this connection to be a Classical IP over ATM (CLIP) connection.

connection name

wan connection <#>

connection name <name-string>

Configures: Sets the name for a particular connection.

Default: None

Description:

User defined name for the connection.

nat

wan connection <#>

nat {enable | disable}

Configures: Enables NAT functionality for a particular connection.

Default: enabled

Description:

Enable/Disable NAT.

firewall

wan connection <#>

firewall {enable | disable}

Configures: Enables the firewall functionality for a particular connection.

Default: enabled

Description:

Enable/Disable the firewall.

upnp

wan connection <#>

upnp {enable | disable}

Configures: Enables the UPnP functionality for a particular connection.

Default: disabled

Description:

Enable/Disable UPnP. UPnP can only be active on a single connection at a time.

igmp

wan connection <#>

igmp {enable | disable}

Configures: Enables IGMP (proxy) functionality for a particular connection.

Default: disabled

Description:

Enable/Disable IGMP. IGMP can only be active on a single connection at a time.

vlan

wan connection <#>

vlan {enable | disable}

Configures: Connection sharing

Default: enabled

Description:

This command enables connection sharing using VLAN tag mechanism.

vlan id

wan connection <#>

vlan id <vlan-id>

Configures: Connection sharing

Default: None

Description:

This command sets the VLAN tag ID for a particular connection to allow connection sharing. Range: vlan-id <1..1024>

atm pvc wan connection <#>

atm pvc <vpi> <vci>

Configures: Creates an ATM PVC

Default: None

Description:

This command creates an ATM Permanent Virtual Circuit (PVC).

Parameters:

vpi: The Virtual Path Identifier of the PVC. The value can be from 0 to 255

vci: The Virtual Channel Identifier of the PVC. The value can be from 0 to 1023.

vpi and vci may not both be 0.

atm qos ubr wan connection <#>

atm qos ubr

Configures: UBR type QoS service for the WAN ATM channel specified.

Default: None

Description:

This command sets UBR type QoS service for the WAN ATM channel specified by the context.

Parameters: None.

atm qos cbr wan connection <#>

atm qos cbr <pcr> [cdvt <cdvt-num>]

Configures: CBR type QoS service for the WAN ATM channel specified.

Default: None

Description:

This command sets CBR type QoS service for the WAN ATM channel specified by the context.

Parameters:

pcr: peak cell rate. Units = cells per second

cdvt: cell delay variance threshold. Units = usecs

atm qos vbr wan connection <#>

atm qos vbr <pcr> [scr <scr-num>] [[mbs <mbs-num>] [cdvt <cdvt-num>]

Configures: VBR type QoS service for the WAN ATM channel specified.

Default: None.

Description:

This command sets VBR type QoS service for the WAN ATM channel specified by the context.

Parameters:

pcr: peak cell rate. Units = cells per second

scr: sustainable cell rate. Units = cells per second

mbs: maximum burst size. Units = cells

cdvt: cell delay variance threshold. Units = usecs

ppp authentication type wan connection <#>

ppp authentication type { auto | pap | chap }

Configures: Authentication type for PPP

Default: auto

Description:

This command enables Auto, PAP or CHAP authentication on the connection specified. This command works for both PPPoE and PPPoA.

ppp authentication username wan connection <#>

ppp authentication { username <user> | password <pass> }

Configures: Username and Password for PPP Authentication

Default:

Description:

This command sets the PPP username and password. This command works for both PPPoE and PPPoA.

ppp connection-mode wan connection <#>

```
ppp connection-mode { {on-demand [idle-timeout <idle-time>]} | {keep-alive [keepalive-time]} }
```

Configures: PPP connection mode.

Default: idle-timeout = 60 seconds, keep-alive = 10 minutes

Description:

This command sets the connection mode type for a ppp connection. The type can be either on-demand or keep-alive. The respective optional parameters idle-timeout, and keepalive-time can be set depending on the connection mode choosen. Ranges: keep-alive <1..100>, idle-timeout <0..60000>. This command is applicable for both PPPoE and PPPoA.

ppp mtu wan connection <#>

```
ppp mtu <bytes>
```

Configures: The mtu parameter for both PPPoE and PPPoA connections.

Default: 1492 bytes

Description:

This command is used to set the MTU parameter for PPPoE and PPPoA connections. See also the command **enforce-mtu**. Range: <128..1500>

ppp enforce-mtu wan connection <#>

```
ppp enforce-mtu {enable | disable}
```

Configures: The firewall ability to enforce the MTU parameter on PPPoE connections.

Default: Disabled

Description:

This command sets the firewall ability to enforce the MTU parameter that is set on a particular PPPoE connection.

ppp default-route wan connection <#>

```
ppp default-route {enable | disable}
```

Configures: The PPP set-route functionality for PPPoE and PPPoA connections.

Default: enabled

Description:

This command is used to set the set-route functionality for PPPoE and PPPoA connections.

ppp debug wan connection <#>

```
ppp debug {enable | disable}
```

Configures: Enables debug capability for PPPoE and PPPoA connections.

Default: disabled

Description:

This command is used to enable debug functionality for PPPoE and PPPoA connections. If log level = debug, and PPP debug is enabled the user will see additional PPP specific debug messages on the default console.

ppp encapsulation

wan connection <#>

```
ppp encapsulation {llc | vc }
```

Configures: The encapsulation method for PPPoA.

Default: llc

Description:

This command sets the encapsulation method for a PPPoA connection. The encapsulation type can be either Bridged LLC or Bridged VC-MUX encapsulation. This command is not used for PPPoE.

static

wan connection <#>

```
static <ip-address> [netmask <mask>] [gateway <ip-address>]
```

Configures: A static rfc2684 type connection

Default: The netmask defaults to a class C network, but can be configured.

Description:

This command configures a new rfc2684 static connection.

static encapsulation

wan connection <#>

```
static encapsulation {llc | vc} [mode {routed | bridged}]
```

Configures: The encapsulation method of the static connection

Default: llc-bridged

Description:

This command set the encapsulation method of the static connection. The following choices are available:

llc-bridged

vc-bridged

llc-routed

vc-routed

dns static

wan connection <#>

dns static [primary <ip-address>] [secondary <ip-address>] [tertiary <ip-address>]

Configures: Static DNS entries

Default: 0.0.0.0 for all parameters

Description:

This command adds the specified DNS entries for a particular WAN Static connection.

dns static-clear

wan connection <#>

dns static-clear

Configures: Static DNS entries

Default: None

Description:

This command deletes all DNS entries for a particular WAN Static connection.

dhcp

wan connection <#>

dhcp {llc | vc}

Configures: DHCP configured WAN connection.

Default: None

Description:

Configure a new DHCP connection.

Parameters:

llc: LLC encapsulation

vc: VC-MUX encapsulation.

dhcp renew

wan connection <#>

dhcp renew

Configures: DHCP addresses for WAN connections.

Default: None

Description:

This command is used to renew DHCP leases for WAN connections.

dhcp release wan connection <#>
dhcp release

Configures: DHCP addresses for WAN connections.

Default: None

Description:

This command is used to delete DHCP leases for WAN connections.

clip wan connection <#>
clip <ip-address> <net-mask> <server-ipaddress> [default-gateway <gateway-ipaddress>]

Configures: Classical IP over ATM (CLIP) interface.

Default: None

Description:

Configure a new CLIP connection.

Parameters:

ip: IP address of the local interface connection
netmask: netmask for local interface connection
server-gateway: IP address of the server side of the CLIP connection.

bridge encapsulation wan connection <#>
bridge encapsulation {llc | vc}

Configures: The encapsulation method used for a bridged connection.

Default: llc

Description:

This command set the encapsulation method for a bridged connection. The encapsulation method can either be Bridged LLC or Bridged VC-MUX.

ipqos wan connection <#>
ipqos {enable | disable}

Configures: Enables IP QoS services on the egress side of an connection interface.

Default: Disabled

Description:

IP QoS services in the NSP is applicable to the output device (Egress side). IP QoS traffic shaping is associated with any transmitted traffic from the perspective of the NSP. Each output device has 3 priority queues associated with any transmit traffic. The High priority queue has strict priority over the medium and low priority queues. The Medium and Low priority queues are serviced on a Round Robin priority basis according to the configured weights (WRR) set with the ipqos queue command, after the High priority queue has been completely serviced.

ipqos trusted-mode

wan connection <#>

ipqos trusted-mode {enable | disable}

Configures: The trusted mode for IP QoS services.

Default: Disabled

Description:

The NSP can operate in either “Trusted” (enabled) or “Untrusted” (disabled) mode of operation with regard to queue traffic prioritization. In “Trusted” mode all the rules will be applied first, regardless of the setting of the TOS bits. After the rules have been exhausted the existing TOS bit settings will be honored. The “Un-trusted” mode will match first against all rules as in “Trusted” mode. The difference is that if there is no match then a default rule will be used. The default rule will have an associated queuing priority – Low.

ipqos queue

wan connection <#>

ipqos queue [low <percentage>] [med <percentage>]

Configures: The low and medium priority queues used on transmit traffic from the modem.

Default: low = 40, med = 60

Description:

This command allows the setting of the Low and Medium priority queues in increments of 10 percent, so that the sum of the weights of these two queues equals 100 percent. The high priority queue is preconfigured.

ipqos rule-add

wan connection <#>

ipqos rule-add <name-string> [parameters]

Configures: Add rules to be used by IP QoS priority queues.

Default: None

Description:

This command allows a user to specify new rules for Add new rules for queuing transmit traffic. One or more of the following parameters can be specified. Wildcard (*) entries are allowed for IP Address/Netmask and Port range fields.

Parameters:

```
name <rule-name>
src-ip: <ip-address>
src-netmask: <mask>
src-start-port: <ip-address>
src-end-port: <ip-address>
dst-ip: <ip-address>
dst-netmask: <mask>
dst-start-port: <ip-address>
dst-end-port: <ip-address>
protocol: {any | icmp | tcp | udp}
physical-port <port-number>
priority {low | medium | high}: Select the queue priority for this rule.
tos { no-change | normal | min-cost | max-reliability | max-throughput | min-delay
}
```

ipqos rule-del

wan connection <#>

ipqos rule-del <index-number>

Configures: Delete rules to be used by IP QoS priority queues.

Default: None

Description:

This command deletes a rule specified by index-number from the list of rules used for IP QoS on a particular connection. Use **show ipqos rule** to get a listing of valid ipqos rules and their associated index numbers.

ipqos rule-clear

wan connection <#>

ipqos rule-clear

Configures: Delete all rules to be used by IP QoS priority queues.

Default: None

Description:

This command deletes all rules used for IP QoS on a particular connection.

route static-add

wan connection <#>

route static add <destination-ip> <netmask> <gateway-ip> [metric <number>]

Configures: Static routes

Default: None

Description:

This command is used to add and configure static routes. Range: number <0..1>

route static-del wan connection <#>

route static-del <index-number>

Configures: Static routes

Default: metric = 0

Description:

This command is used to delete a static route by specifying its index number. Use **show route static** to get a listing of valid static routes and their associated index numbers.

route static-clear wan connection <#>

route static-clear

Configures: Static routes

Default: metric = 0

Description:

This command is used to delete all static routes.

port forward wan connection <#>

port forward {enable | disable}

Configures: Port Forwarding.

Default: None

Description:

This command enables Port Forwarding.

port forward rule-add wan connection <#>

port forward rule-add [parameters]

Configures: Port Forwarding Rules for a particular connection.

Default: None

Description:

This command allows the user to add rules for the port forwarding function. A connection must be specified for which the rule applies.

Parameters:

name <rule-name>

protocol <tcp | udp | tcp-udp | any>
src-ip <ip-address>
src-netmask <mask>
dst-ip <ip-address>
dst-netmask <mask>
port-start <port-number>
 Starting value of port numbers to be used. Range <0..65535>
port-end <port-number>
 Ending value of port numbers to be used. Range <0..65535> and greater than the Start Value.
port-map <port-number>
 Port map specifies the starting port number from which to re-map the range of port numbers given by port-start, and port-end.

port forward rule-del wan connection <#>

port forward rule-del <index-number>

Configures: Port Forwarding Rules.

Default: None

Description:

This command allows the user to delete a specific rule for the port forwarding function. Use **show port forward rule** to get a listing of valid port forward rules and their associated index numbers.

port forward rule-clear wan connection <#>

port forward rule-clear

Configures: Port Forwarding Rules.

Default: None

Description:

This command clears all rules for the port forwarding function.

dmz wan connection <#>

dmz {enable | disable }

Configures: DMZ

Default: None

Description:

This command enables DMZ functionality.

dmz client-add

wan connection <#>

dmz client-add <ip-address>

Configures: DMZ

Default: None

Description:

This command allows the user to set the LAN client IP used for the DMZ. Only one LAN client IP can be specified at a time. The client IP must be chosen from those added through **dhcp client-static add**. A command does not exist to explicitly clear a client IP address because these are added and deleted via the **dhcp client-static add** and **delete** commands. The **dmz {disable}** command must be used to disable the dmz while a dhcp client-static IP address exists on the system.

access-list

wan connection <#>

access-list {enable | disable}

Configures: Access control

Default: None

Description:

This command enables the access control list for the modem.

access-list service

wan connection <#>

access-list service [parameters]

Configures: Access control list

Default: None

Description:

This command enables services for the access control list.

Parameters:

telnet <disabled | enabled>

web <disabled | enabled>

ftp <disabled | enabled>

tftp <disabled | enabled>

ssh <disabled | enabled>

snmp <disabled | enabled>

access-list ip add

wan connection <#>

```
access-list ip add <ip-address>
```

Configures: Access control list

Default: None

Description:

This command adds IP addresses on the access control list.

Warning: The IP addresses assigned through this command have a global scope.

access-list ip del

wan connection <#>

```
access-list ip del <index-number>
```

Configures: Access control list

Default: None

Description:

This command deletes IP addresses on the access control list. Use **show access-list** to get a listing of valid access-list ip numbers and their associated index numbers.

access-list ip clear

wan connection <#>

```
access-list ip clear
```

Configures: Access control list

Default: None

Description:

This command deletes all IP addresses on the access control list.

show [all]

wan connection <#>

Configures:

Default:

Description:

Show configuration settings of all connections

show connections

wan connection <#>

Configures:

Default:

Description:

Show the basic settings of the WAN connection

show atm

wan connection <#>

Configures:

Default:

Description:

Show the ATM settings

show dns

wan connection <#>

Configures:

Default:

Description:

Show the static DNS entries

show dhcp

wan connection <#>

Configures:

Default:

Description:

Show the DHCP connection settings

show clip

wan connection <#>

Configures:

Default:

Description:

Show the CLIP connection settings

show bridge

wan connection <#>

Configures:

Default:

Description:

Show the bridge connection settings

show static wan connection <#>

Configures:

Default:

Description:

Show the static connection settings

show ppp wan connection <#>

Configures:

Default:

Description:

Show the PPP connection settings

show route wan connection <#>

Configures:

Default:

Description:

Show route information

show route static wan connection <#>

Configures:

Default:

Description:

Show the static route list

show port-forwarding wan connection <#>

Configures:

Default:

Description:

Show the port forwarding rules

show ip-qos

wan connection <#>

Configures:

Default:

Description:

Show IP-QoS configuration

ROOT: ADVANCED - CONTEXT

The following CLI commands are available from the ADVANCED context.

router rip

advanced

router rip {enable | disable}

Configures: RIP Protocol

Default: Disabled

Description:

This command enables the RIP protocol.

router rip protocol

advanced

router rip protocol {ripv1 | ripv2 | ripv1compatible} [direction {in | out | both}]

Configures: RIP Protocol

Default: Protocol = ripv1, Direction = both

Description:

This command configures the RIP protocol for the modem.

router rip authentication

advanced

router rip authentication {enable | disable} [password <string>]

Configures: Sets the password used for the RIP protocol

Default: None.

Description:

This command sets the password used for the RIP protocol. Empty passwords are allowed.

snmp agent

advanced

snmp agent {enable | disable}

Configures: SNMP agent

Default: Disabled

Description:

This command enables the SNMP agent.

snmp traps

advanced

snmp traps {enable | disable}

Configures: SNMP traps

Default: Disabled

Description:

This command enables the SNMP traps.

snmp system

advanced

snmp system [name <name-string>] [location <name-string>] [contact <name-string>]

Configures: SNMP parameters

Default: name = "sptcroute", location = "germantown,md,usa", contact = "support@telogy.com"

Description:

This command sets local SNMP parameters.

snmp community set

advanced

snmp community set <slot> name <strName> [access-right {read-only | read-write}]

Configures: SNMP community parameters

Default: access-right = readonly

Description:

This command sets SNMP community parameters. A limit of 3 communities can be configured. The system has a default of name = "public" and access-right = "readonly" configured. Therefore, without deleting this entry, there will be only 2 more entries allowed.

snmp community clear

advanced

snmp community clear {all | <slot> }

Configures: SNMP community parameters

Default: None

Description:

This command deletes SNMP community parameters. Specify all to delete all entries, or specify slot to specify 1 of 3 individual entries.

snmp traps set

advanced

snmp traps set <slot> <ip-address> trap-community <strName> trap-version {snmpv1 | snmpv2c}

Configures: SNMP trap parameters

Default: trap-community = public, trap-version = snmpv1

Description:

This command sets SNMP trap parameters. A limit of 3 traps can be configured.

snmp traps clear

advanced

snmp traps clear {all | <slot>}

Configures: SNMP trap parameters

Default: None

Description:

This command deletes SNMP trap parameters. Specify all to delete all entries, or specify slot to specify 1 of 3 individual entries.

sntp

advanced

sntp {enable | disable}

Configures: SNTP Time Server

Default: Disabled

Description:

This command enables the SNTP time server.

sntp server

advanced

sntp server [primary <ip-address>] [secondary <ip-address>] [tertiary <ip-address>]

Configures: SNTP server

Default: 0.0.0.0 for all parameters

Description:

This command sets the SNTP timeserver IP addresses.

sntp timeout

advanced

sntp timeout <seconds>

Configures: SNTP server

Default: None

Description:

This command sets the SNTP timeserver timeout. Range: <0..30>

sntp retries

advanced

sntp retries <integer>

Configures: SNTP server

Default: 2

Description:

This command sets the SNTP timeserver retry limit. Range: <0..5>

sntp polling-interval

advanced

sntp polling-interval <integer>

Configures: SNTP server

Default: 30

Description:

This command sets the SNTP timeserver polling interval. Range: <0..30>

sntp timezone

advanced

sntp timezone <timezone-string>

Configures: SNTP server

Default: GMT

Description:

This command sets the SNTP timeserver timezone.

Enumerated types for timezone-string:

```
{"NZST", "New Zealand Standard Time"}  
{"JST", "Japan Standard Time"}  
{"KST", "Korea Standard Time"}  
{"CCT", "China Coast Time"}  
{"IST", "India Standard Time"}  
{"IT", "Iran Time"}  
{"BT", "Baghdad Time"}  
{"EET", "Eastern European Time"}  
{"CET", "Central European Time"}  
{"GMT", "Greenwich Mean Time"}  
{"AT", "Azores Time"}  
{"BST", "Brazil Standard Time"}  
{"AST", "Atlantic Standard Time"}  
{"EST", "Eastern Standard Time"}  
{"CST", "Central Standard Time"}  
{"PST", "Pacific Standard Time"}  
{"YST", "Yukon Standard Time"}  
{"HST", "Hawaii Standard Time"}
```

show [all]

advanced

Configures:

Default:

Description:

Show the configuration of all advanced features

show access-list

advanced

Configures:

Default:

Description:

Show all access control list information on WAN and LAN groups

show snmp

advanced

Configures:

Default:

Description:

Show SNMP configuration information

show sntp

advanced

Configures:

Default:

Description:

Show SNTP configuration information

show web-filter

advanced

Configures:

Default:

Description:

Show the configuration information of web filter

show multicast

advanced

Configures:

Default:

Description:

Show multicast configuration

show rip

advanced

Configures:

Default:

Description:

Show RIP configuration

show static-route

advanced

Configures:

Default:

Description:

Show static route configuration
