

A-OMNI-0232

Packing Check List

Item	Description	Quantity
	For A-OMNI-0232	
1	A-OMNI-0232 Antenna	1
2	M18 Nut ss	1
3	M18 Star Washers ss	1

Installation Instructions

Best antenna performance will be achieved by mounting the antenna on a metal surface.

1. Use the cut out antenna base template below to mark the centre point where the hole must be drilled.
2. Once the centre point is marked, drill a hole 18.5mm to 19mm wide.
3. Debur the edges of the hole and make sure that the area around the hole is clean and grease free.
4. Remove the wax protection paper from the 2x foam seals at the base of the antenna.
5. Insert the antenna threaded spigot through the drilled hole.
6. Fit the spring washer and nut from the inside of the mounting plate.
7. Tighten the M18 Nut to 20Nm torque. Be careful not to over tighten the nut.

