

Connecting an ADSL-FFP85D



The incoming pair of wires should be connected to 2 and 5 on the left hand side.

If you require further filtered extensions (telephone only) these should be connected to F2 and F5 on the right hand side, if you need to send the ring signal then you need to connect a 3rd wire to F3 (This would be connected to terminal 3 on your extension).

If you wish to send an unfiltered signal for an ADSL connection elsewhere, then you should run this from 2 and 5. NC=Not connected.