

The PL-85PEW MK2 Wireless HomePlug

Your 85PEW_MK2 comes with a DHCP server enabled by default. This means it will supply equipment plugged into your network with IP addresses. This can cause problems if you have a router on your network doing this as well. To disable DHCP mode, please follow these instructions.

Plug the 85PEW into the mains and connect it to your computer either with an ethernet cable or wirelessly. Open a web browser (e.g. Internet Explorer) and in the address bar put in 192.168.1.1 (user: **admin Password: admin**) this will take you to the configuration screen of the PEW.

You then need to click on "LAN" then "Lan settings" tick **disable** in the DHCP server section. Then click submit. After 1 minute unplug and re-plug the unit and follow the instructions in the manual for any further configuration required.