

How To Access the Web Interface of the E2000M

Please take care in changing the settings on the web interface as it is possible to permanently lock yourself out of the web interface, especially if you change the admin password and later forget it.

The unit's default IP address is 10.10.10.240, so you will need to set up a static IP address of 10.10.10.xxx on your computer to access it.

You will also need to have connected an Ethernet cable from the LAN port of a computer to the LAN port of the E2000M unit.

Once you have satisfied both requirements, open a browser and type 10.10.10.242 into the address bar.

The web interface will not load, and you will be then prompted for a password to sign in.

The default password is pasterna.

Once logged in, navigating the web interface should be self-explanatory.